

QUICK REFERENCE

Exemplar OpenBoot

Order No. DSW-854
Part No. 710-029430-001
OBP Version 3.0 Field Trial Edition
October 1996

Hewlett-Packard Company
Convex Division
3000 Waterview Parkway
P.O. Box 833851
Richardson, TX 75083-3851
United States of America

Exemplar OpenBoot Quick Reference

Order No. DSW-854
Document No. 710-029430-001

© Copyright Hewlett-Packard Company 1996. All Rights Reserved. Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws. Sun, Sun Microsystems, the Sun logo and OpenBoot are trademarks or registered trademarks of Sun Microsystems, Inc.

Notice

The information contained in this document is subject to change without notice.

Hewlett-Packard makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Hewlett-Packard shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance or use of this material.



This entire book is recyclable.

Printed in the United States of America

Syntax

Commands entered at the OpenBoot ok prompt are executed left-to-right after pressing <RETURN>. Enter multiple commands on a single line separated by one or more spaces.

Help Commands

help Lists main help categories.

Emergency Keyboard Commands

<ESC> Hold down during boot sequence. Interrupts auto-boot sequence when *auto-boot?* parameter is true.

System Information Display Commands

banner Displays the power-on banner.
date *[datestring]* Displays or set the clock/calendar chip date. (Syntax like HP-UX *date(8)* command.)
lifs *//flash@1,0* Lists Firmware directory in Flash RAM.
list Verifies boot files intact in a directory.
.memory Displays the current hypervisor memory configuration.
.obp Displays the OBP loader release and build version.
.post Displays POST release number.

Alias Commands

dealias Displays all current device aliases.
dealias *alias* Displays the device path for corresponding *alias*.
dealias *alias device-path* Defines a temporary alias representing the device path. If an alias with the same name already exists, the new value supersedes the old. Use *nvalias* to permanently change alias in NVRAM.
nvalias alias device-path Stores *dealias alias device-path* in NVRAMRC. (Alias persists until *nvunalias* or *set-defaults* command executes.)
nvunalias alias Deletes the named alias from NVRAMRC. Run *reset* to clear aliases.

Device Tree Commands

.attributes Displays the current node properties.
.properties Alias for .attributes.
cd *device-path* Selects the indicated device node, making it the current node.
cd *node-name* Selects the first node with the given name in the subtree below the current node.
cd .. Selects the device node that is the parent of the current node.
cd / Selects the root machine node.
device-end Deselects the current device node, leaving no node selected.
go Begins execution of a loaded program or resumes execution of a halted program.
ls Lists device paths.
pwd Displays the device path name that names the current node.
show-devs *[device-path]* Displays all the devices known to the system directly beneath a given level in the device hierarchy.
words Displays the names of the current node's methods.

Boot Commands

boot *[device] [boot-directory] [boot-arguments]*

<i>[device]</i>	Full device path name or alias. Examples: sd0a (alias for default SCSI disk root partition) rmt0 (alias for default SCSI DAT install tape drive) /pci@fe,10000/qisp@0,0/scl@2,0:afddi0 (alias for FDDI network controller)
<i>[boot-directory]</i>	HFS full directory pathname in the boot partition contacting the three boot files (mach, server, tunables).
<i>[boot-arguments]</i>	-s Boots SPP-UX in single-user mode. (if boot-file=mach) -mk_debug Microkernel waits for kgdb to attach. -halt Halt after loading (e.g., to set breakpoints). -noheader boot-file is not a.out. (.fth or CODE files).
load	Loads SPP-UX or a stand-alone program and returns to the ok prompt without starting the program. Use go to start the loaded program. Command arguments same as boot.
reset	Resets system. Similar to invoking do_reset from the test station.
soft-reset	Resets system forcing core mode reboot. (Debug mode.)

Viewing and Changing Configuration Parameters

mkmap <i>[-n] unit device</i>	Defines an SPP-UX logical-unit to physical-unit mapping, a label for tape and network devices unlike disk labels. The -n switch creates a logical-unit property with no physical unit information; use with network adaptors only.
password	Sets the security mode password. Prompts for an 8 character password and verification.
printenv <i>[parameter]</i>	Displays all current and default values (usually shown as decimals). printenv <i>parameter</i> displays the named parameter current value.
rmmmap <i>device</i>	Undefines a mapping created with mkmap.
show-map <i>[device unit]</i>	Displays the logical unit mapping for named device or all entries with same logical unit number. Used alone, displays all logical-unit mappings for the current hypernode.
setenv <i>[+g -g] parameter value</i>	Sets the parameter to named decimal or text value. +g sets the global attribute, -g clears it. The global attribute causes Exemplar OBP to automatically update the designated parameter on every hypernode. (To set a numeric parameter using a hexadecimal number, use the OBP word to, e.g.: h# 30 screen-#rows
set-default <i>parameter</i>	Resets the named parameter value to factory default.
set-defaults	Resets all parameter values to factory defaults. (Note: This function takes about 60 seconds to complete).

Restricted Monitor Commands

b <i>[-s]</i>	Same as boot.
c	Same as go.

NVRAMRC Editor Commands

<code>nvedit</code>	Invokes the NVRAMRC editor. Edit either temporary buffer data present from a previous <code>nvedit</code> session or current NVRAMRC contents.
<code>nvquit</code>	Discards temporary buffer contents without writing to NVRAMRC. Prompts for confirmation.
<code>nvrecover</code>	Enters the editor and recovers NVRAMRC contents lost by <code>set-defaults</code> execution if <code>nvedit</code> was not executed since the NVRAMRC contents loss and <code>nvrecover</code> execution.
<code>nvrun</code>	Executes temporary buffer contents.
<code>nvstore</code>	Copies temporary buffer contents to NVRAMRC.

NVRAMRC Editor Navigation Commands

	Prev. Line	Beg. Line	Prev. Word	Prev. Char	Next Char	Next Word	End Line	Next Line
Move	<code>^P</code>	<code>^A</code>	<code>!B</code>	<code>^B</code>	<code>^F</code>	<code>!F</code>	<code>^E</code>	<code>^N</code>
Delete		<code>^U</code>	<code>^W</code>	<code>Del</code>	<code>^D</code>	<code>!D</code>	<code>^K</code>	
	Retype line			<code>^R</code>				
	Show all lines			<code>^L</code>				
	Paste after			<code>^K</code>	<code>^Y</code>	<code>^?</code>	<code>^_</code>	
	Complete command			<code>^space</code>				
	Show all matches			<code>^/</code>				

! = Press and release Escape key first; ^ = Press and hold Control key

Using the NVRAMRC Editor

```
ok nvedit
:
(use editor commands)
:
^C                               (get back to ok prompt)
ok nvstore                       (save changes)
ok setenv use-nvramrc? true      (enable NVRAMRC)
```

NVRAM Variables

NVRAM Variable Default Value Type	Description
<code>input-device</code> /core@f0,f0000000/tty:a	Console input, output and error output devices. The RS232 port A on the node. Not accessible from UNIX.
<code>output-device</code> /core@f0,f0000000/tty:a	
<code>stdcon-device</code> /core@f0,f0000000/tty:a	
<code>screen-#columns</code> 80	Line wrap and page screen settings. Set <code>screen-#rows</code> to 0 to disable paging. Use when terminal has scrollbar
<code>screen-#rows</code> 24	
<code>pciprobe?</code> true	When false, prevents OBP from probing PCI I/O system. For debugging only.

<i>pci[0]-fcode-enable</i> 0	Enable booting up to three SCSI controllers for designated PCI bus. Values are a comma delimited list of PCI slot numbers (0,1,2).
<i>pci[1]-fcode-enable</i>	
<i>pci[2]-fcode-enable</i>	
<i>pci[3]-fcode-enable</i>	
<i>pci[4]-fcode-enable</i>	
<i>pci[5]-fcode-enable</i>	
<i>pci[6]-fcode-enable</i>	
<i>pci[7]-fcode-enable</i>	
<i>tyb-rts-dtr-off</i> false	Controls tty device driver. Currently nonfunctional.
<i>tyb-ignore-cd</i> true	
<i>ttya-rts-dtr-off</i> false	
<i>ttya-ignore-cd</i> true	
<i>tyb-mode</i> 9600,8,n,1,-	
<i>ttya-mode</i> 9600,8,n,1,-	
<i>fcode-debug?</i> false	When true, lets FCode drivers print more information as they boot.
<i>local-mac-address?</i> true	When true, sets <i>/core/lan</i> device driver to use built-in node serial number to derive the ethernet physical address. When false, user must set the OBP <i>system-mac-address</i> value to load firmware or boot OS from network using ethernet and NFS.
<i>ramdisk-offset</i> 1c000000	Sets physical address OBP uses to load ramdisk images. Used by kernel developers only.
<i>tz</i> CST6CDT,92/03:00,302/01:00	Controls timezone and daylight savings time conversion rules for date command I/O. Syntax same as <i>TZ</i> variable in HP-UX <i>environ(5)</i> man page.
<i>diag-device</i> /core@f0, f0000000/lan@0, d30000	When the <i>diag-switch?</i> flag is true, OBP uses these as implicit arguments for boot or load commands. When <i>diag-switch?</i> is true, OBP will not load tunables or server files. Currently used only in the lab.
<i>diag-directory</i> diag-directory	
<i>diag-file</i> diag-file	
<i>boot-device</i> /pci@fe,10000/qlisp@0,0/sd@2,0:a	
<i>boot-directory</i> /stand/spp3	Specifies program(s) OBP loads when <i>diag-switch?</i> is false. If value is mach, OBP loads both tunables and server. If value is hpux, OBP loads only the named <i>boot-file</i> . If value is vmunix and <i>boot-mode</i> is hpux, OBP boots the PDCBOOT firmware loader which boots ISL, HP-UX and the /vmunix kernel using normal HP-UX boot software. If <i>boot-device</i> value is <i>/core@f0,f0000000/lan@0,d3000</i> , <i>boot-directory</i> changes.
<i>boot-file</i> mach	
<i>boot-args</i>	
<i>dns-ip#</i> <no default>	

<i>cluster-boot?</i> false	When true, causes OBP to boot each node in a hypernode cluster as an independent machine. Not used in single node OBP 3.0 release.
<i>load-tunables?</i> true	Obsolete. Ignored by OBP 3.0
<i>system-mac-address</i> <no default>	Tells OBP the <i>/core/lan</i> device physical ethernet address to use. Format is parameter <i>x:x:x:x:x:x</i> and must be set only when <i>local-mac-address?</i> value is false.
<i>udp-log#</i> <no default>	UDP port number to use to log events to test station.
<i>unit-map</i> <no default>	Tape and network peripherals mapping table used by <i>show-map</i> , <i>mkmap</i> and <i>rmmap</i> .
<i>use-nvramrc?</i> false	When a user edits the <i>nvramrc</i> file to execute Forth commands during the boot process, set this flag to true. Creating a non-volatile device alias with <i>nvalias</i> automatically sets this flag to true and commands are placed in the <i>nvramrc</i> file.
<i>nvramrc</i>	Forth script OBP executes during the latter phase of booting and before probing the I/O system.
<i>security-mode</i> none	Used to restrict access to the interactive OBP command mode.
<i>security-password</i>	
<i>security-#badlogins</i> <no default>	
<i>last-hardware-update</i> <no default>	Stores a string containing last machine modification date. A typical use would be to type the <i>date</i> command at the ok prompt then use <i>setenv</i> to set the <i>last-hardware-update</i> string using the current date.
<i>mfg-switch?</i> false Boolean flag	Resets all parameters to defaults at next OBP reboot if NVRAM becomes corrupted. Ignored by OBP 3.0.
<i>diag-switch?</i> false boolean flag	Sets <i>diagnostic-mode?</i> to true with boots OBP from <i>diag-device</i> instead of <i>boot-device</i> and <i>diag-file</i> instead of <i>boot-file</i> . Also displays new device names as they are compiled into the device tree at I/O system probe time.
<i>auto-boot?</i> false	Determines if OBP is set to reboot the operating system after a reset. If true, OBP automatically probes the I/O system and boots the system using current <i>boot-device</i> , <i>boot-directory</i> and <i>boot-args</i> values.
<i>watchdog-reboot?</i> false	Determines if OBP automatically reboots after a watchdog reset. Currently non-functional.

<i>boot-mode</i> core	Determines the memory map and OBP boot loader capabilities. In core mode, OBP is only a diagnostic tool. The PCI I/O system is not probed nor available. It is used automatically after a soft reset due to a hard error. In sppux mode, OBP boots the OS then copies itself to RAM. In sppux mode, OBP uses 0x1000-0x000ffff. In hpux mode, OBP uses 0x04f00000-0x4ffff.
<i>cache-error-fdce</i> false	Debug flags generally never set to true.
<i>cache-error-reset</i> false	
<i>hypernode-bitmask</i> 0	Little-endian bitmask of hypernodes in the complex. Multinode OBP only.
<i>cpu-clock-speed</i> 0	If 0, OBP causes each CPU to self-calibrate its clock frequency using the Exemplar Time-of-Century counter as a known frequency standard. If set to one a permitted value (120 or 180), indicates the frequency in Megahertz OBP will use to calibrate the CPU.
<i>nvr-erase?</i> false	OBP is unable to boot and reset default values if NVRAM is corrupt. When true, OBP clears all previous NVRAM settings enabling the <code>set-defaults</code> operation. Set to true from the test station using the diagnostic shell command: <code>put 0:0xf0fd04050 0xff000000.</code>
<i>rdr9</i> 00000001.20000000	Values PDC_ENTRY and OBP use for the diagnose register initial contents when a machine is reset.
<i>dr2</i> 00000000.00000000	
<i>nrp-msg-port#</i> 4098	Controls the UDP port numbers OBP uses in multinode configurations to communicate with OBP on other nodes in the complex. Values must be the same on each node.
<i>pty-recv-port#</i> 4097	
<i>pty-send-port#</i> 4096	
<i>simulator-mode?</i> false	Set to true when OBP boots in software simulation to avoid errors due to deviations from actual hardware. Should always be false on actual hardware.
<i>pim-save-first?</i> false	Used in the machine check handler to alter the overwriting rules. If true, multiple HPMC or TOC will not overwrite the first occurrence. When false, only the most recent HPMC or TOC is saved.
<i>alternate-obp?</i> false	When true, OBP located in the TC area will boot instead of OBP located in the Opera.

The remaining options, accessible via OBP's `printenv/setenv` commands, are shared with POST firmware. In some cases, OBP uses the actual parameter, such as an IP address. In most cases, OBP simply sets or displays a value used only by POST. In some cases, OBP retains and resets a default value used when OBP discovers corrupted NVRAM. For options without an OBP default, the NVRAM value remains unchanged after the recovery process.

<i>post-revision</i> <no default>	Treat as a read-only parameter containing the POST firmware software version.
<i>obp-ip#</i> <no default>	A four part, period delimited, decimal Internet protocol number (e.g., 1.2.3.4) for OBP to use as the <code>/core/lan</code> address.
<i>ts-ip#</i> <no default>	Test station Internet protocol number to which the <code>/lan</code> device is attached.
<i>boot-module</i> obp	Set to OBP when POST (power on selftest) completes.
<i>monarch#</i> 0	Booting control processor number in a multiple CPU configuration
<i>force-monarch?</i> false	Affects both POST and OBP monarch choice. When true, specifies the CPU to use as the boot monarch processor. When false, both POST and OBP select the monarch randomly.
<i>selftest?</i> true	When true, POST executes selftests on each CPU coming out of reset. Applies to all CPUs enabled for booting. See <code>cpu[X]</code> .
<i>cachetest?</i> true	When true, POST executes selftests on each CPU coming out of reset. Caches are always initialized but tested only when this option is true.
<i>ecubtest?</i> true	When true, POST monarch processor performs ECUB (Core utility) tests.
<i>cti-cache-size</i> 0 Megabytes	A decimal number of megabytes of RAM POST configures as network cache when a machine is interconnected in a multinode complex.
<i>high-availability?</i> <no default>	If true, POST configures the memory controller ASICs to use <i>high-availability</i> mode. The POST default value is false.
<i>use-7bit-id?</i> <no default>	If true, a multinode complex uses 7-bit node ids. The POST default value is false (5 bit node id).
<i>xring-only?</i> <no default>	Diagnostic flag specifying the ring topology of a nonstandard multinode configuration. Currently unused.
<i>80bit-dimms?</i> false	Flag informing POST of DRAMS size installed in the memory boards. Usually false in single node configurations.
<i>reduced-bandwidth?</i> false	If true, POST configures the memory subsystem for reduced bandwidth mode.

<i>verify-dimms?</i> false	If true, POST performs a destructive memory test during memory initialization. Normally, POST initializes only the tags and parity of the memory lines using diagnostic CSR writes without performing CPU loads and stores to memory.
<i>master-error-enable?</i> true	If true, POST uses default values for all ASIC error config values. If false and <i>use-error-overrides?</i> is false, POST sets all ASIC error config registers to zeros.
<i>use-error-overrides?</i> false	If false, POST uses current NVRAM error config parameters instead of POST defaults. If true, <i>master-error-enable?</i> is ignored.

The following POST options are ASIC error config register initial value only if *use-error-overrides?* is true.

<i>emuc-ee</i> <no default>	Specifies the CORE MUC FPGA error enable bits.
<i>epuc-ee</i> <no default>	Specifies the CORE PUC FPGA error enable bits.
<i>erac[0]-ee</i> ed80	Specifies the Crossbar ASIC error enable bits.
<i>erac[1]-ee</i> ed80	
<i>erac[2]-ee</i> ed80	
<i>erac[3]-ee</i> ed80	
<i>epac[0]-ee[0]</i> ffffeab.ffffe000	Specifies each of the two 64-bit error enable register contents for each of 8 EPAC ASICs.
<i>epac[0]-ee[1]</i> ffe5d6bb.ebfffff	
<i>epac[1]-ee[0]</i> ffffeab.ffffe000	
<i>epac[1]-ee[1]</i> ffe5d6bb.ebfffff	
<i>epac[2]-ee[0]</i> ffffeab.ffffe000	
<i>epac[2]-ee[1]</i> ffe5d6bb.ebfffff	
<i>epac[3]-ee[0]</i> ffffeab.ffffe000	
<i>epac[3]-ee[1]</i> ffe5d6bb.ebfffff	
<i>epac[4]-ee[0]</i> ffffeab.ffffe000	
<i>epac[4]-ee[1]</i> ffe5d6bb.ebfffff	
<i>epac[5]-ee[0]</i> ffffeab.ffffe000	
<i>epac[5]-ee[1]</i> ffe5d6bb.ebfffff	
<i>epac[6]-ee[0]</i> ffffeab.ffffe000	
<i>epac[6]-ee[1]</i> ffe5d6bb.ebfffff	
<i>epac[7]-ee[0]</i> ffffeab.ffffe000	
<i>epac[7]-ee[1]</i> ffe5d6bb.ebfffff	

<i>emac[0]-ee[0]</i> 5faaff9.b7ffffab	Specifies each of the two 64-bit error enable register contents for each of 8 MAC ASICs.
<i>emac[0]-ee[1]</i> 00000000.00fff569	
<i>emac[1]-ee[0]</i> 5faaff9.b7ffffab	
<i>emac[1]-ee[1]</i> 00000000.00fff569	
<i>emac[2]-ee[0]</i> 5faaff9.b7ffffab	
<i>emac[2]-ee[1]</i> 00000000.00fff569	
<i>emac[3]-ee[0]</i> 5faaff9.b7ffffab	
<i>emac[3]-ee[1]</i> 00000000.00fff569	
<i>emac[4]-ee[0]</i> 5faaff9.b7ffffab	
<i>emac[4]-ee[1]</i> 00000000.00fff569	
<i>emac[5]-ee[0]</i> 5faaff9.b7ffffab	
<i>emac[5]-ee[1]</i> 00000000.00fff569	
<i>emac[6]-ee[0]</i> 5faaff9.b7ffffab	
<i>emac[6]-ee[1]</i> 00000000.00fff569	
<i>emac[7]-ee[0]</i> 5faaff9.b7ffffab	
<i>emac[7]-ee[1]</i> 00000000.00fff569	
<i>epic[0]-ee</i> 1557abea.b6aaaa01	Specifies the 64-bit error enable register contents for each of 8 PIC ASICs.
<i>epic[1]-ee</i> 1557abea.b6aaaa01	
<i>epic[2]-ee</i> 1557abea.b6aaaa01	
<i>epic[3]-ee</i> 1557abea.b6aaaa01	
<i>epic[4]-ee</i> 1557abea.b6aaaa01	
<i>epic[5]-ee</i> 1557abea.b6aaaa01	
<i>epic[6]-ee</i> 1557abea.b6aaaa01	
<i>epic[7]-ee</i> 1557abea.b6aaaa01	

<i>etac[0]-ee</i> d7d65597.bfdffffd5	Specifies the 64-bit error enable register contents for each of 8 TAC (SCI) ASICs.
<i>etac[1]-ee</i> d7d65597.bfdffffd5	
<i>etac[2]-ee</i> d7d65597.bfdffffd5	
<i>etac[3]-ee</i> d7d65597.bfdffffd5	
<i>etac[4]-ee</i> d7d65597.bfdffffd5	
<i>etac[5]-ee</i> d7d65597.bfdffffd5	
<i>etac[6]-ee</i> d7d65597.bfdffffd5	
<i>etac[7]-ee</i> d7d65597.bfdffffd5	

The next set of config parameters constitutes a portion of the POST Boot Config Map. These values change as a side effect of POST configuration and are not simply user configurable options. For instance, if the user tries to enable `cpu[1]` and it is not installed, POST sets the value to `empty`. POST uses these values to set map parameters:

enable or *unknown*

POST autoconfigures the component.

disable

POST software deconfigures the component.

fail

The component failed a test. `pass` is normal and the component is usable.

pass

The component is normal and usable.

disabled

The user deconfigured the component by setting its value to `disable` and rebooting.

deconfig

POST deconfigured the component due to configuration rules enforced when a component is manually disabled or unavailable due to test failure.

<i>cpu[0]</i> unknown	CPU module config map.
<i>cpu[1]</i> unknown	
<i>cpu[2]</i> unknown	
<i>cpu[3]</i> unknown	
<i>cpu[4]</i> unknown	
<i>cpu[5]</i> unknown	
<i>cpu[6]</i> unknown	
<i>cpu[7]</i> unknown	
<i>cpu[8]</i> unknown	
<i>cpu[9]</i> unknown	
<i>cpu[10]</i> unknown	
<i>cpu[11]</i> unknown	
<i>cpu[12]</i> unknown	
<i>cpu[13]</i> unknown	
<i>cpu[14]</i> unknown	
<i>cpu[15]</i> unknown	
<i>epac[0]</i> unknown	PAC config map.
<i>epac[1]</i> unknown	
<i>epac[2]</i> unknown	
<i>epac[3]</i> unknown	
<i>epac[4]</i> unknown	
<i>epac[5]</i> unknown	
<i>epac[6]</i> unknown	
<i>epac[7]</i> unknown	

<i>epic</i> [0] unknown	PIC config map.
<i>epic</i> [1] unknown	
<i>epic</i> [2] unknown	
<i>epic</i> [3] unknown	
<i>epic</i> [4] unknown	
<i>epic</i> [5] unknown	
<i>epic</i> [6] unknown	
<i>epic</i> [7] unknown	
<i>erac</i> [0] unknown	Crossbar Config map.
<i>erac</i> [1] unknown	
<i>erac</i> [2] unknown	
<i>erac</i> [3] unknown	